

數位講桌操作說明

有問題請打分機：

5371(教具室)

5082(黃先生)

▶ 系統開機



輕觸七吋螢幕

點選中間的開始使用開啟系統以及麥克風

▶ 情境控制

按下桌上電腦

開啟講桌電腦
以及開啟投影機
及布幕



按下筆記電腦

開啟投影機及布幕
顯示外接訊號源

關閉所有系統



單獨控制設備

設備控制




單獨控制設備
開關(按壓兩秒)

控制訊號源音
量大小聲

控制麥克風音
量大小聲

切換投影機及
螢幕訊號來源

系統關機



關閉所有系統

有問題請打分機：
5371(教具室)
5082(黃先生)

Digital Lectern Operation Instructions

▶ System startup



Double tap screen on
Click the "Start Using"
button in the center to turn
on the system

▶ Scene Control



Turn on the lectern
computer, projector
and projection
screen

Turn on the
projector and
projection screen,
and display the
external input signal
source

Turn off all systems

Individual Device
Control

▶ Device Control



Individual device on/off control
(press and hold for 2 seconds)
(Left: Computer, Middle: Projector,
Right: Projection Screen tap on/off)


Control the volume level of the
input signal source(PC/NB)

Control the microphone
volume level

Switch the input source

Left: to Scene Control
Right: Turn off all systems

▶ System shutdown



Cancel the system
shutdown

Confirm to shut down all
systems

For more helps, please call extension:
5371(Teaching AID Room)
5082 (Mr. Huang)